






Installation instructions

Instructions de montage
Montageanleitung
Montage instructie
Istruzioni di montaggio

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergeleri
Οδηγίες συναρμολόγησης
Instrukcja montażu

Szerelési utasítások
Návod k montáži
ИНСТРУКЦИЯ ПО МОНТАЖУ
Návod k montáži



P



Ø mm



RS120B, Fixed

4x LED

13W

75



0,27

RS121B, Adjustable



86

0,33






Fixed



Adjustable



PHILIPS



- Only to be installed outside arms reach as recessed ceiling luminaire.
- If the external flexible luminaire cable or cord is damaged, it shall be exclusively repaired/replaced by the manufacturer or his service agent or a similar qualified person in order to avoid hazard.
- For complete and updated list of advised dimmers, please check the CoreLine ProSet page on the Philips Lighting eCatalog: <http://www.ecat.lighting.philips.com>