


AAV9064101-03

Manufacturer
 Schneider Electric Industries SAS
 35, rue Joseph Monier
 92506 Rueil Malmaison France

UK Importer
 Schneider Electric Ltd, Stafford Park5,
 Telford, TF3 3 BL, UK





X1 → X8

RJ45

1	Commande sens 1 / Direction 1 control / Mando dirección 1 / Управление направлением 1
2	Commande sens 2 / Direction 2 control / Mando dirección 2 / Управление направлением 2
3	Commun des sorties / Output common / Común de salidas / Общий выход
4	NC
5	Etat des pôles / Status of poles / Estado de los polos / Состояние выхода
6	24 V $\overline{\text{=}}$ des sorties / 24 V $\overline{\text{=}}$ for outputs 24 V $\overline{\text{=}}$ de salidas / 24 В $\overline{\text{=}}$ для выходы
7	Défaut / Fault / Falla / Неисправность
8	Commun des entrées / Input common / Común de entradas / Общий вход

**X9
HE10**

- 24 V Aux	(20)	(19)	+ 24 V Aux	
- 24 V Aux	(18)	(17)	+ 24 V Aux	
X8	(16)	(15)	X7	} Etat des pôles/ Status of poles / Estado de los polos / Состояние выхода
X6	(14)	(13)	X5	
X4	(12)	(11)	X3	
X2	(10)	(9)	X1	
X8	(8)	(7)	X7	} Défait / Fault / Falla / Неисправность
X6	(6)	(5)	X5	
X4	(4)	(3)	X3	
X2	(2)	(1)	X1	

**X10
HE10**

- 24 V Aux	(20)	(19)	+ 24 V Aux	
- 24 V Aux	(18)	(17)	+ 24 V Aux	
X8	(16)	(15)	X7	} Commande sens 2 / Direction 2 control / Mando dirección 2 / Управление направлением 2
X6	(14)	(13)	X5	
X4	(12)	(11)	X3	
X2	(10)	(9)	X1	
X8	(8)	(7)	X7	} Commande sens 1 / Direction 1 control / Mando dirección 1 / Управление направлением 1
X6	(6)	(5)	X5	
X4	(4)	(3)	X3	
X2	(2)	(1)	X1	