








CONTROL BOX 3S RTS

- FR** Manuel d'installation - Illustrations
- EN** Installation instructions - Illustrations
- DE** Montageanleitung - Abbildungen
- NL** Installatiehandboek - Illustraties
- PL** Instrukcja montażu - Ilustracje
- RU** Руководство по установке — иллюстрации
- CS** Instalační příručka – Ilustrace
- RO** Manual de instalare - Ilustrații


- IT** Manuale di installazione - Illustrazioni
- ES** Manual de instalación - Ilustraciones
- EL** Εγχειρίδιο εγκατάστασης - Εικόνες
- TR** Montaj kılavuzu - Şekiller
- FA** راهنمای نصب - تصاویر
- AR** دليل التركيب - الرسوم التوضيحية




7





8




9





A $\overline{PO7} = 1$




B $\overline{PO7} = 3$




C $\overline{PO7} = 4$




11




12




13




14




15




16




17





18





19



20



Ref. 1841021



21



22



23




24




25




26




27




28



29



30



SOMFY ACTIVITES SA

50 avenue du Nouveau Monde

74300 CLUSES

FRANCE

www.somfy.com

somfy®

EAC CE

