









CONTROL BOX 3S io

- FR** Manuel d'installation - Illustrations
- EN** Installation instructions - Illustrations
- DE** Installationsanleitung - Abbildungen
- NL** Installatiegids - Illustraties
- PL** Instrukcja montażu - Ilustracje
- HU** Telepítési kézikönyv - Ábrák
- CS** Návod k montáži - obrázek
- RO** Manual de instalare - Ilustrații
- IT** Manuale d'installazione - Illustrazioni


- ES** Manual de instalación - ilustraciones
- EL** Εγχειρίδιο εγκατάστασης - Εικόνες
- TR** Montaj kılavuzu - örneklemeler
- AR** دليل التركيب





A $\overline{PO7} = 1$




B $\overline{PO7} = 3$




C $\overline{PO7} = 4$




11




12




13




14




15




16





17




18




19



Ref. 1841021



20




21




22




23




24




25




26




27




28




29




30




31




32




33




34




35




36



37



38



SOMFY ACTIVITES SA
 50 avenue du Nouveau Monde
 74300 CLUSES
 FRANCE

www.somfy.com

